

WOOL COMBERS

SCHLUMBERGER, SANT'ANDREA PS, PSL,
SACM-SAG, SACM-PERL, PRINCE SMITH,
MITSUBISHI AND SHINKO PLB

First Combing (Opener) #0755HS, #4555A,
#0660, #1300A,

First Combing (Finisher) #0943HSF,
#1243A, #1800A

Re-Combing or Synthetic Combing
(Opener) #0750
(Finisher) #1700

For NSC PB-30 (Opener, Front) #0545
(Opener, Rear) #0755HS
(Finisher) #0943HSF